

# Porovnávací tabulka pro hubičky v 1/1000 palců

Bb-klarinet																					
Otevření dráhy INCH	39	40	42	43	44	45	46	47	48	50	54	55	56	58	60	65	68	71			
Backun	CRT	LRT	TRT	ORT	ORT+			ART2													
Brillhart						2	3	4	5												
Otto Link					4*		5			6			6*								
Rico Royal						3				5			7								
USA-Meyer						4				5			6		7	8	9	10			

Sopran-saxofon																					
Otevření dráhy INCH	45	48	50	51	52	54	55	57	58	59	60	61	63	65	67	68	70	72	73	75	80
Brancher											15			17							20
Claude Lakey													4*				5*			6*	7*
Lebayle			6								7						8				
Otto Link	4*		5				5*				6		6*	7		7*	8		8*		
Rico Royal							3				5			7							
Rousseau Classic	3R	4R		5R																	
Rousseau New Classic																					
Rousseau Studio Jazz									SJ6			SJ7					SJ8				
USA-Meyer		4		5		6		7		8		9	10								
Vandoren		s15								s25								s35			
Yanagisawa Kautschuk		4			5		6		7				8		9						

Alt-saxofon																																
Otevření dráhy INCH	57	58	60/61	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	80	81	82	83	85	86	87	89	90	92	95	98	
Brancher																	19						21					23				
Brillhart									2			3			4			5		6			7	8								
Claude Lakey																				4*			5*				7*					
Lebayle															6					7								8				
Otto Link			4*			5					5*				6				6*			7*					7*		8			
Rico Royal											3									5								7				
Rousseau Classic			3R	4R			5R																									
Rousseau New Classic		NC3	NC4		NC5																											
Rousseau JDX						4			5	6			7		8																	
Rousseau Jazz						4			5	6			7		8																	
Rousseau Studio Jazz						4		5		6		7		8																		
Rousseau Jazz Metall											5		6						7			8				9						
USA-Meyer																																
Vandoren																																
Yanagisawa Kautschuk																																
Yanagisawa Metall																																

Tenor-saxofon																															
Otevření dráhy INCH	68	69	71	72	74	75	76	77	78	79	80	81	82	85	86	90	92	95	97	98	100	101	102	104	105	107	109	110	113	115	120
Brancher																		25								27				29	
Brillhart Ebonil			2		3			4			5				6	7				8									9		
Brillhart Level Air				3				4					5		6	7				8									9		
Claude Lakey																			4*						5*			7*		8*	
Lebayle														6					7										8		
Otto Link						4*					5			5*		6		6*			7					7*		8		8*	9
Rico Royal														3					5							7					
Rousseau Classic	3R			4R			5R																								
Rousseau New Classic																															
Rousseau JDX																				4			5		6		7		8		
Rousseau Jazz																				4			5		6		7		8		
Rousseau Studio Jazz																				4			5		6		7		8		
Rousseau Jazz Metall																	5		6			7				8			9		
USA-Meyer			4				5					6			7		8			9					10						
Vandoren		T27								T25	T20										T55				T75			T77			
Yanagisawa Kautschuk			4				5							6		7						8					9				
Yanagisawa Metall										5					6		7					8		8				9			

Bariton-saxofon																							
Otevření dráhy INCH	70	76	82	85	86	88	90	92	93	94	95	98	100	103	104	105	109	110	115	117	119	120	124
Brancher																27			29				
Lebayle																			7	7*			8
Otto Link				4*			5				5*		6		6*			7	7*				8
Rico Royal							3							5					7				
Rousseau Classic	3R	4R	5R			6R				7R													
Rousseau JDX														5			6		7		8		
USA-Meyer					4			5				6			7			8		9			10
Yanagisawa					5					6			7				8		9				